



Configuration  
based on post slots  
located at top




FRONT

REAR

Refer to drawings  
U-1045-1 & U-1080  
for fastener lists




Doors may be removed from frame during installation.  
In multiple consecutive bay installations,  
be sure to pair doors with original frames.




FRONT




Use mutual fasteners  
where Door Set frames meet



Line up mounting tabs  
in Rear Panels  
with accessible post holes



Only one End Panel  
required between  
bay sections  
where desired



REAR