

## **OPERATING INSTRUCTIONS**

1. Secure platform to forklift before use.
2. Engage brake before elevating platform.
3. Do not transport personnel while elevated.
4. Inspect all safety features before each use.
5. Secure safety lanyard when using platform.
6. Latch gate before use.
7. Do not use near high voltage.
8. Operate on level ground only.
9. Confirm forklift capacity before use.

**MODEL# 510      LOAD CAPACITY - 500 LBS.**

**EMPTY PLATFORM WEIGHT - 165 LBS.**

**MINIMUM LIFT TRUCK CAPACITY - 2500 LBS.**

**MINIMUM LIFT TRUCK TRACK WIDTH - 36 IN.**

Unitran model 510 work platform conforms to ANSI/ITSDF B56.1-2016 safety standard